


LED Make-Up Mirror

en Instructions for use



Safety warnings

Read the safety warnings carefully and only use the product as described in these instructions to avoid accidental injury or damage. Keep these instructions for future reference. If you pass this product on to another person, remember to give them these instructions.

Intended use

The product is designed for private use and is not suitable for commercial purposes.

DANGER to children

- Children are not aware of the risks associated with improper use of electronic devices. Therefore, keep the product out of the reach of children.
- Keep the packaging material out of the reach of children. It poses several risks, including the risk of suffocation!

DANGER due to electricity

- Do not make any modifications to the product. Only have repairs to the product carried out by a specialist workshop. Improper repairs can result in considerable risks to the user.
- When charging the battery in the LED mirror, observe the following:
 - The LED mirror must not be charged in the bathroom or in damp rooms.
 - If the LED mirror has got wet, allow it to dry completely before connecting it to the mains power supply with the USB charging cable.

- Do not place any containers filled with liquid, such as vases, etc., on or near the product. The container could tip over and the liquid may affect the safety of the electronics inside. Risk of electric shock.
- Only use suitable charging devices for charging the product.
- Do not use or attempt to repair faulty charging devices.
- Do not connect the LED mirror to the power supply if the mirror itself or the USB charging cable shows visible signs of damage.

WARNING – risk of burns/fire

- You cannot and must not attempt to replace or remove the built-in rechargeable battery on your own. If the rechargeable battery is removed or replaced improperly, there is a risk of explosion. Only have the battery replaced with the same or a comparable rechargeable battery. If the rechargeable battery is faulty, consult a specialist workshop.
- Do not place any open flames, e.g. burning candles, in the vicinity of the product. Candles and other open flames must always be kept at a distance from the product in order to prevent potential fires from spreading.
- The product contains a lithium-polymer rechargeable battery. This must not be taken apart, thrown into fire or short-circuited.
- Do not change, deform, heat up or dismantle rechargeable batteries.

CAUTION – material damage

- Do not immerse the LED mirror or the USB charging cable in water or other liquids.
- Ensure that no liquids are able to enter the USB connection socket.
- Position the USB charging cable in such a way that the LED mirror cannot be accidentally pulled down by the cable while it is charging.
- The USB charging cable must not be bent or crushed. Keep the USB charging cable away from sharp corners and sources of heat.
- Do not expose the product to any hard impacts and protect it from dust, moisture, direct sunlight exposure and extreme temperatures.
- Do not use abrasive or caustic cleaning agents, or hard brushes, etc., for cleaning.
- The built-in LEDs cannot and must not be replaced.
- Some varnishes, synthetic substances and types of furniture polish may react adversely with the material of the non-slip feet and soften them. To avoid unwanted marks on furniture, place a non-slip mat underneath the product if necessary.


Technical specifications

Model:	678 370
Rechargeable battery:	Lithium-polymer 3.7 V  1000 mAh
(tested as per UN 38.3)	Watt-hour rating: 3.7 Wh (non replaceable)
Input:	5 V  0.4 A (the  symbol stands for direct current)
Charging time:	approx. 3.5 hours
Operating time:	approx. 6 hours
Bulb:	LEDs (5500 K: daylight)
Ambient temperature:	+10 to +40 °C
Made exclusively for:	Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany

Charging the battery

To prevent damage to the rechargeable battery, the product is only half charged upon delivery. Therefore, charge the rechargeable battery fully before using the product for the first time by connecting it to the mains power supply using a mains adapter (not included).

You can switch on the LED lights while the battery is charging, however this will extend the time required to charge the product.




1. Insert the end of the USB charging cable into the connection socket on the side of the LED mirror.
2. Connect the other end of the USB charging cable to a wall socket using a suitable mains adapter (not included).

The charging indicator light lights up red while the device is charging. When empty, the rechargeable battery can be fully charged in approx. 3.5 hours. Once the battery is fully charged, the charging indicator light turns green.

3. When the device is charged, remove the mains adapter from the wall socket and disconnect the USB charging cable from the LED mirror.

When fully charged, you can use the LED lights in the mirror for approx. 6 hours. If the LED lights no longer switch on, then the rechargeable battery must be fully recharged.

Switching the LED light on and off



1. Gently tap the on/off switch at the bottom of the mirror's surface to switch on the surrounding LED lights and dim them: bright > dimmer > dim > bright, etc.

The LED lights are always bright when the mirror is switched on.

2. Touch the on/off switch and leave your finger in this position to switch off the LED lights again.

Cleaning

- ▷ Wipe the base and frame with a soft, slightly damp cloth as required.
- ▷ Carefully clean the surface of the mirror using a soft cloth, slightly dampened with clean water (do not use glass cleaner!) then wipe it dry. Do not allow any moisture to enter the USB connection socket!

Disposal

This product, its packaging and the enclosed rechargeable battery have been manufactured from valuable materials that can be recycled. Recycling reduces the amount of refuse and helps to preserve the environment.

Dispose of the **packaging** at a recycling point that sorts materials by type. Make use of the local facilities provided for collecting paper, cardboard and lightweight packaging.

 **Devices** marked with this symbol as well as flat **standard/rechargeable batteries** must not be disposed of along with household refuse!

You are legally obliged to dispose of all old devices separately from household waste and to take flat batteries and flat at a local authority collection point or to return them to a battery retailer.

Electronic devices, standard and rechargeable batteries contain both useful materials and hazardous substances and, if stored or disposed of improperly, may cause harm to health or the environment.

Warning! This device contains a rechargeable battery that, for safety reasons, is firmly built into the device. It cannot be removed without destroying the casing. Improper disassembly leads to safety hazards. Therefore, bring the device intact to a collection point where the device and battery will be disposed of properly.



Product number: 678 370


www.tchibo.de/instructions



(Please enter the product number in the box labelled "Bedienungsanleitungssuche" and click on "Suchen")

LED kozmetik aynası

tr Kullanım Kılavuzu



Güvenlik uyarıları

Güvenlik uyarılarını dikkatle okuyun. Kaza sonucu ortaya çıkabilecek yaralanmaları ve hasarları önlemek için ürünü yalnızca bu kullanım kılavuzunda belirtildiği şekilde kullanın. Gerekliğinde tekrar okumak üzere bu kılavuzu saklayın. Bu ürün başkasına devredildiğinde, bu kılavuz da beraberinde verilmelidir.

Kullanım amacı

Bu ürün özel kullanım için tasarlanmış olup ticari amaçlar için uygun değildir.

Çocuklar için TEHLİKE

- Çocuklar, elektrikli cihazların hatalı kullanılması sonucu oluşabilecek tehlikeleri fark edemez. Bu nedenle çocukları ürünün uzak tutun.
- Çocukları ambalaj malzemesinden uzak tutun. Aksi takdirde boğulma tehlikesi vardır!

Elektriğin sebep olabileceği TEHLİKELER

- Üründe herhangi bir değişiklik yapmayın. Üründe yapılması gereken onarımları sadece yetkili bir servise yaptırın. Usulüne uygun olmayan onarımlar sonucu kullanıcı için büyük tehlikeler oluşabilir.
- LED aynanın şarjlı pilini şarj ederken dikkat edilmesi gerekenler:
 - LED ayna banyoda veya nemli mekanlarda şarj edilmemelidir.
 - LED kozmetik aynası ıslanacak olursa, USB şarj kablosu ile elektrik prizine takmadan önce iyice kurutun.

- Ürünün üzerine veya yakınına örn. vazo benzeri veya içi sıvı dolu kapları bırakmayın. Bu kapların devrilmesi durumunda, içlerindeki sıvılar, elektrikli cihazlarda tehlike oluşturur. Elektrik çarpması tehlikesi oluşur.
- Şarj etmek için sadece uygun şarj cihazları kullanın.
- Arızalı şarj cihazları kullanmayın ve bunları onarmaya çalışmayın.
- LED kozmetik aynasının kendisinde veya USB şarj kablosunda gözle görülür hasarlar varsa aynayı elektrik prizine bağlamayın.

Yanma/yangın UYARISI

- Entegre Şarjlı pil değiştirilemez ve değiştirilmemelidir. Şarjlı pil usulüne uygun olarak değiştirilmediğinde, patlama tehlikesi mevcuttur. Sadece aynı veya aynı özelliklere sahip şarjlı pil tipleri ile değiştirilmelidir. Şarjlı pil arızalandığında, lütfen uzman bir atölyeye başvurun.
- Ürünün yakınına mum gibi açık alev kaynakları yerleştirmeyin. Mumlar ve diğer açık alevler, yangının yayılmasını engellemek için her zaman üründen uzak tutulmalıdır.
- Ürün bir lityum polimer şarjlı pil içermektedir: Bunlar bölünmemeli, ateşe atılmamalı veya kısa devre yapılmamalıdır.
- Şarjlı pilleri değiştirmeyin ve/veya deforme etmeyin/ısıtmayın /parçalarına ayırmayın.

DİKKAT - Maddi hasar tehlikesi var

- LED kozmetik aynayı ve USB şarj kablosunu suya veya diğer sıvılara daldırmayın.
- USB bağlantı soketine nem girmemesine dikkat edin.
- USB kablosunu, şarj esnasında LED kozmetik aynasının yanlılıkla aşağıya çekilemeyeceği bir şekilde yerleştirin.
- USB şarj kablosu bükülmemeli veya sıkışmamalıdır. USB şarj kablosunu sıcak yüzeylerden ve keskin kenarlı cisimlerden de uzak tutun.
- Ürünü çok fazla sallamayın ve toza, neme, doğrudan güneş ışınına ve aşırı sıcaklıklara karşı koruyun.
- Temizleme için tahriş edici ya da aşındırıcı kimyasallar veya sert fırçalar vb. kullanılmamalıdır.
- Takılmış olan LED'ler değiştirilemez ve değiştirilmemelidir.
- Bazı boyalar, plastikler veya mobilya bakım ürünleri kaymayı önleyen ayakları bulundukları yüzeye etki edebilir ve yumuşatabilir. Mobilyalarda istenmeyen izlerin meydana gelmesini önlemek için gerekirse ürünün altına kayganlığı önleyici bir altlık yerleştirin.


Teknik bilgiler

Model:	678 370
Şarjlı pil:	Lityum polimer 3,7 V — 1000 mAh
(UN 38.3'e göre test edilmiştir)	Nominal güç: 3,7 Wh (değiştirilemez)
Giriş :	5 V — 0,4 A (Bu sembol — doğru akımın göstergesidir)
Şarj süresi:	Yakl. 3,5 saat
Çalışma süresi:	Yakl. 6 saat
Ampul:	LED'ler (5500 K: Gün ışığı)
Ortam sıcaklığı:	+10 ila +40 °C
Tchibo için özel olarak üretilmiştir:	Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany, www.tchibo.com.tr

Şarjlı pili şarj etme

Hasarları önlemek için şarjlı pil, sadece yarıya kadar doldurulmuş olarak teslim edilir. Bu nedenle ilk kullanımdan önce şarjlı pili bir şebeke adaptörü (teslimat kapsamında bulunmaz) üzerinden akım şebekesinde tamamen şarj edin.


LED aydınlatmayı şarj işlemi esnasında çalıştırabilirsiniz ancak bu durumda şarj süresi uzar.



1. USB şarj kablosunun bir ucunu LED kozmetik aynanın yanındaki bağlantı soketine takın.
2. USB şarj kablosunun diğer ucunu uygun bir elektrik adaptörü (teslimat kapsamında yoktur) ile bir prize bağlayın.
3. Şarj işlemi sonrasında elektrik adaptörünü prizden çekin ve USB kablosunu LED kozmetik aynasından çıkarın.

Şarjlı pil tam dolu olduğunda aynanın LED aydınlatması yakl. 6 saat kullanabilirsiniz. LED aydınlatma artık çalıştırılmıyorsa öncelikle şarjlı pilin tekrar tamamen şarj edilmesi gerekir.

LED aydınlatmayı açma ve kapama



1. Ayna yüzeyinin altındaki açma/kapama şalterine hafifçe dokunarak LED aydınlatmayı açın ve kısak için: aydınlık > loş > karanlık > aydınlık vs.
- LED aydınlatmayı açtığınızda her zaman aydınlık konumundadır.

2. LED aydınlatmayı tekrar kapatmak için açma/kapama şalterinin üstüne parmağınızı dokunur halde tutun.

Temizleme

- ▷ Gerekirse ayağı ve çerçeveyi yumuşak, hafif nemli bir bezle silin.
- ▷ Ayna yüzeyini dikkatlice yumuşak sadece biraz soğuk suyla nemlendirilmiş bir bez ile temizleyin (cam temizleyici kullanmayın), ardından tekrar silerek kurutun. USB bağlantı yuvasına nem ulaşmamalıdır!

İmha etme

Ürün, ambalajı ve entegre edilmiş şarjlı pil, tekrar kullanılabilen değerli malzemelerden üretilmiştir. Tekrar kullanım sayesinde atıklar azalır ve çevre korunur.

Ambalajı malzeme türüne göre imha edin. Bunun için bölgenizdeki kağıt, mukavva ve hafif ambalaj toplama merkezlerinin sunduğu imkanlardan faydalanabilirsiniz.



Bu sembolle işaretlenen **cihazlar** ve boş **şarjlı piller/piller** ev atıkları ile birlikte atılmamalıdır! Yasal olarak eski cihazları evsel atıklardan ayrı şekilde imha etmekle ve aynı şekilde boş şarjlı pilleri /pilleri beldenizdeki veya belediyenizdeki bir toplama yerine ya da pil satan yerlerdeki toplama kaplarına bırakmakla yükümlüsünüz. Elektrikli cihazlar, piller ve şarjlı piller hem değerli kaynakları hem de tehlikeli maddeleri içerir. Bunların uygun olmayan şekilde depolanması ve imha edilmesi çevreye ve sağlığa zarar verebilmektedir.

Dikkat! Bu cihazda güvenlik nedenlerinden dolayı sabit konumda takılmış olan ve gövdeye zarar vermeden çıkarılamayacak durumda bir şarjlı pil bulunmaktadır. Kurallara uygun olmayan şekilde sökülmesi, güvenlik riski oluşturur. Bu nedenle cihazı açmadan, cihaz ve şarjlı pili gerektiği şekilde imha eden bir toplama yerine götürün.



Ürün numarası: 678 370

www.tchibo.com.tr/kilavuzlar

